lf you can't recyle make it vanish.

Introducing Sigma Vanish Machine and Hand Film Powered by Eclipse[™] Bio-Assimilation Technology.

Powered by Eclipse[™] Bio-Assimilation Technology

Sigma

Vanish is a state-of-the-art stretch film designed to bio-assimilate beginning 2 years after production. Bio-assimilation is the process of turning something (stretch film), into a renewable material-a food source for a multitude of microorganisms. And the amazing part is that the total bio-assimilation process does not require any special conditions such as oxygen or sunlight.

Product Code	Width	Length	Gauge	Weight/Roll	Rolls/Pallet
MVA5009049	500 mm	9000′	49	34.8	40
MVAS00S0SS	500 mm	8000′	55	34.7	40
MVA5007263	500 mm	7250′	63	36.0	40
MVA5006070	500 mm	6000′	70	33.1	40
MVA5006080	500 mm	6000′	80	37.8	40
MVA50045100	500 mm	4500′	100	35.4	40
MVA50040120	500 mm	4000′	120	37.8	40
				Weight/Case	Cases/Pallet
HVB161447	16″	1476′	47	17.8	64
HVB161452	16″	1476′	52	19.7	64

That's why we say at Sigma, "if you can't recycle it, make it VANISH!"

Sigma Stretch Film Smartplastic



CALL 1-800-565-0606 TO ORDER!

106 Burbridge Ave., Dartmouth, NS B3B 0G7 Email sales@cabotss.com Web www.cabotss.com

Rethinking the potential of stretch film. The four pillars that layout how we can better manage the use of plastic on our planet.

REDUCE

There is a vast difference between an interesting idea and a scalable solution...

Rite-Gauging[©]

RENEW

Add bio-assimilation t short service/one time use films that may end up as litter... Vanish

RECYCLE

Enhance the circular economy with recyclability and procurement as well as increasing the utilization of PCR... Endure

REFRAME

Educate on the role of plastics in safety, preservation, and performance... Packworx


BIO-ASSIMILATION

THE FINAL STAGE OF BIODEGRADATION

Definitively, "bio-assimilation" means that the plastic has degraded to a molecular weight that can be consumed by living organisms.

NO TRACE LEFT BEHIND

This represents the final and conclusive stage of plastic biodegradation, leaving behind no micro-plastics, in both marine and terrestrial environments.




IDEAL CONDITIONS

High UV exposure, heat, humidity and availability of microorganisms.

POOR CONDITIONS

Low UV exposure, heat, humidity and availability of microorganisms.





720 DAYS Dry, low temp., subterranean.

.

â

ė . 180

DAYS

Humid high temp. exposed.



